

Got some faded teak wood that needs a refresh?

with a few simple steps, you can bring it back to life and **make it look as good as new**.

Start by gathering your supplies:



Top Coat AZ2705/00 FNT X EST.TRASP.OPACA LT 25



A brush covered with cloth or a disposable foam brush



120-grit sandpaper



320-grit sandpaper



Cloth and water

Steps:

- 1. Sand the faded wood using 120-grit sandpaper until you see the brownish color of the wood. If available, you can also use a handheld grinder for this step.
- 2. Clean the chair from the wood dust produced by the sanding. You only need to use water for this, and then wait until it dries completely.
- 3.Prepare the top coat solution in a small container, mixing it with water in a 1:1 ratio. Use the brush covered with cloth to apply it to t he smooth wood surface that has been sanded. The cloth covering prevents streaks during application. Then, let it dry in direct sunlight for about 20 minutes.
- 4.Smoothly sand the wood that has been coated with the top coat using 320-grit sandpaper. This step is meant to prepare the surface for a second layer of the top coat. Do not use the handheld grinder for this step.
- 5.Apply the top coat to the wood again using the cloth-covered brush. The cloth helps ensure a smooth application and strengthens the wood's resistance to water. Let it dry in direct sunlight for about 20 minutes.
- 6.Smoothly sand the wood coated with the top coat using 320-grit sandpaper. This final sanding is to ensure a smooth finish after the top coat application. Do not use the handheld grinder for this step.